
ooze

HINGE

FLICK BATTERY



510 THREAD

AUTO OFF

DIGITAL SCREEN

PASS THROUGH CHARGING

BATTERY INDICATOR

CART CONNECT

210 mAh

ooze Warranty Protected

HINGE
FLICK BATTERY

QUICK START GUIDE


1. Press the left side button to flip the 510 thread into position and screw in your cartridge.
2. Click the power button 5x to turn it on.
3. Click the button 3x to change the voltage.
4. Click the button 2x to run a low-heat cycle of Prep Mode, which will clear any clogs in your cartridge.
5. Press and hold the button to take your hit.
6. Press the left side button to fold the cartridge into the storage position, protecting it while not in use.
7. Click the button 5x to turn it off, or it will shut itself off automatically after 12 minutes.

SCREEN GUIDE

Charging

When plugged in, the battery symbol flashes and battery percentage is shown. When it reaches 100%, the battery symbol will disappear. The device can be used while it's plugged in.


The Hinge does not include a charger, but has a type-C charging port for a universal charging cable.




Cart Connect

The blue lock with a check indicates the cart is successfully connected.

The yellow lock means a cart is not connected, or has an issue.



Voltages



SAFE GUARDS

- Keep away from water.
- Only charge indoors.
- Only use in legal and adult use state/providence/country.
- Only use approved Ooze attachments.
- Never leave unattended around children/pets.
- Never disassemble.
- Only use wall outlet for charging.
- Do not leave unattended while charging.
- Do not leave charging overnight.
- Always dry thoroughly after cleaning.

@OOZELIFE #OOZELIFE

WWW.OOZELIFE.COM