
ooze®

TRAVELER SERIES 0420 0420



SMELL PROOF

LUGGAGE STRAP

CONCEALED LOCK

WATER BOTTLE POCKET

STORAGE POCKETS

PADDED STRAPS

OOZE LINING

How to Set Your Backpack Combination Lock

1. Access the lock by pulling the cover flap up.
2. The lock is preset to 0-0-0. Determine the 3-digit combination you want to set.
3. Push the button and keep holding it while you select your chosen combination.
4. Release the button.
5. Your new combination is now set.
   - *Note: there is no way to open the lock if you forget your combination! Make sure you file it away in a safe place.*
6. You can reset the lock to have a different 3-digit passcode as many times as you'd like! Repeat the steps in this manual, holding the button when your current passcode is input.